



Furniture Foot Application

**All Stock Furniture Feet (without services) are shipped unfinished and without any holes or hardware*

Hardware Options



2" Hanger Bolt
[Part #925](#)
Metal to Wood
Application



4" Hanger Bolt
[Part #920](#)
Metal to Wood
Application



4" Hanger Bolt
(w/nut & washer)
[Part #930](#)
Metal to Wood
Application



2" Screw Dowel
[Part #916](#)
Wood to Wood
Application



4" Screw Dowel
[Part #910](#)
Wood to Wood
Application

Services Available from Osborne

Drill Hole – Less than 3" deep in various diameters (No Hardware)

Install Bolt/Screw – Install 910W, 916HW, 920HW, 925HW or 930HW into top center of Foot

Custom Install Hardware- Install hardware at various depths/locations on Foot

[Learn More About our Furniture Foot Services](#)

**All orders including services must be placed by phone at 1-800-849-8876*

Installing Furniture Feet



DIY Tutorial Video
*Installing a bun foot using a
Screw Dowel*

[WATCH NOW](#)



DIY Tutorial Video
*Installing a bun foot using
Wood Screws*

[WATCH NOW](#)



DIY Tutorial Video
*Installing a bun foot using
Wood Dowels*

[WATCH NOW](#)